



Cant Rail Upgrade Kit Instructions

- 1/. Fit the 2 x anodised aluminium B pillar clips in place of the old plastic ones using the M5 caphead screws provided
- 2/. Remove the old steel clip from the cant rail (2 screws)
- 3/. The kit uses one original screw hole from your old cant rail; the other needs a 2mm hole drilling into the cant rail then screw in the 2nd stainless steel screw provided.

Once installed it should look like this.

